

SCHEDULED MAINTENANCE CHECK SHEET

(all models with 10,000 miles (16,000 km) service intervals)



Customer Name	Registration Number	Date of Registration
Model	VIN	Odometer Reading
Bike Under Warranty? <input type="checkbox"/> Yes <input type="checkbox"/> No	Service Book Stamped? <input type="checkbox"/> Yes <input type="checkbox"/> No	Job Number
Date	Technician Name	Technician Signature

Carry out all the operations specified below at the required intervals. Additional operations must be carried out at the specified time/distance interval, whichever comes first.
IMPORTANT: Under severe operating conditions, certain items require more frequent servicing. Refer to the Owner's Handbook for further information.

First Service - First 500 miles/800 km /1 Month (whichever comes first)	Annual Service - Every year	Additional items at specified mileage/date only, as indicated below
---	-----------------------------	---

First Service	<input checked="" type="checkbox"/>	Tick Box when Item Complete
Annual Service	<input type="checkbox"/>	
10,000 and 30,000 miles (16,000 and 48,000 km)	<input type="checkbox"/>	Not Applicable to this Model
20,000 miles (32,000 km)	<input type="checkbox"/>	
40,000 miles (64,000 km)	<input type="checkbox"/>	
Lubrication		
		Engine and oil cooler - check for leaks
		Engine oil - renew
		Engine oil filter - renew
Fuel System and Engine Management		
		Autoscan - carry out a full Autoscan using the Triumph diagnostic tool (print a customer copy)
		Fuel system - check for leaks
		Fuel system - check fuel hoses for chafing, cracks or damage. Replace if necessary
		Air cleaner - renew
		Air cleaner - renew (Bonneville Bobber, Bonneville T100, Bonneville T120, Street Cup, Street Scrambler, Street Twin, Thruxton 1200, Thruxton 1200R, Trophy, Trophy SE, Tiger Explorer only)
		Fuel filter - renew (if fitted)
		Throttle body plate (butterfly) - check/clean
		Throttle cables - check function and adjust as necessary (models with a cable operated throttle only)
		Throttle bodies - balance
		Fuel hoses - renew - every 4 years, regardless of mileage ⁴
		Evaporative hoses - renew (if fitted) - every 4 years, regardless of mileage ⁴
Ignition System		
		Spark plugs - check
		Spark plugs - renew
Cooling System (liquid cooled models only)		
		Cooling system - check for leaks
		Cooling system - check coolant hoses for chafing, cracks or damage. Replace if necessary
		Coolant level - check/adjust
		Coolant - renew - every 3 years, regardless of mileage ⁴

First Service	<input checked="" type="checkbox"/>	Tick Box when Item Complete
Annual Service	<input type="checkbox"/>	
10,000 and 30,000 miles (16,000 and 48,000 km)	<input type="checkbox"/>	Not Applicable to this Model
20,000 miles (32,000 km)	<input type="checkbox"/>	
40,000 miles (64,000 km)	<input type="checkbox"/>	
Engine		
		Clutch cable - check function and adjust as necessary (models fitted with a cable clutch only)
		Clutch master cylinder - check for fluid leaks (models fitted with a hydraulic clutch only)
		Clutch fluid level - check (models fitted with a hydraulic clutch only)
		Clutch fluid - renew - every 2 years regardless of mileage (models fitted with a hydraulic clutch only) ⁴
		Valve clearances - check/adjust ⁴
		Camshaft timing - check/adjust ⁴
Wheels and Tyres		
		Wheels - inspect for damage
		Wheel bearings - check for wear/smooth operation
		Wheels - check for broken or damaged spokes and check spoke tightness (not alloy wheels)
		Tyre wear/tyre damage - check
		Tyre pressures - check/adjust
Steering and Suspension		
		Steering - check for free operation
		Front and rear suspension - check for damage/leaks/smooth operation
		Fork oil - renew
		Headstock bearings - check/adjust - except first service
		Headstock bearings - lubricate
		Rear suspension unit and linkage - lubricate (single rear suspension unit models only)
Brakes		
		Brake pads - check wear levels ³
		Brake master cylinders - check for fluid leaks
		Brake calipers - check for fluid leaks and seized pistons ⁴
		Brake fluid levels - check
		Brake fluid - renew - every 2 years, regardless of mileage ⁴

SCHEDULED MAINTENANCE CHECK SHEET - CONTINUED

(all models with 10,000 miles (16,000 km) service intervals)



First Service	<input checked="" type="checkbox"/>	Tick Box when Item Complete
Annual Service	<input checked="" type="checkbox"/>	Tick Box when Item Complete
10,000 and 30,000 miles (16,000 and 48,000 km)	<input type="checkbox"/>	
20,000 miles (32,000 km)	<input type="checkbox"/>	
40,000 miles (64,000 km)	<input type="checkbox"/>	
Drive Chain		
<input type="checkbox"/>	<input type="checkbox"/>	Drive chain slack - check/adjust
<input type="checkbox"/>	<input type="checkbox"/>	Drive chain - wear check ³
<input type="checkbox"/>	<input type="checkbox"/>	Drive chain - lubricate
<input type="checkbox"/>	<input type="checkbox"/>	Drive chain rubbing strip - check for wear, cracks or damage ³
Final Drive		
<input type="checkbox"/>	<input type="checkbox"/>	Final drive - check for oil leaks
<input type="checkbox"/>	<input type="checkbox"/>	Final drive oil level - check (Rocket III, Rocket III Classic, Rocket III Touring and Rocket III Roadster models only)
<input type="checkbox"/>	<input type="checkbox"/>	Final drive oil - renew (Rocket III, Rocket III Classic, Rocket III Touring and Rocket III Roadster models only)
<input type="checkbox"/>	<input type="checkbox"/>	Final drive oil level - check (Trophy, Trophy SE, Tiger Explorer only)
<input type="checkbox"/>	<input type="checkbox"/>	Final drive oil - renew - only first service (Trophy, Trophy SE, Tiger Explorer only)
Electrical		
<input type="checkbox"/>	<input type="checkbox"/>	Lights, instruments and electrical systems - check/adjust

First Service	<input checked="" type="checkbox"/>	Tick Box when Item Complete
Annual Service	<input checked="" type="checkbox"/>	Tick Box when Item Complete
10,000 and 30,000 miles (16,000 and 48,000 km)	<input type="checkbox"/>	
20,000 miles (32,000 km)	<input type="checkbox"/>	
40,000 miles (64,000 km)	<input type="checkbox"/>	
General		
<input type="checkbox"/>	<input type="checkbox"/>	Instruments ¹ , chassis ECM ² and engine ECM - check for latest calibration download using the Triumph diagnostic tool
<input type="checkbox"/>	<input type="checkbox"/>	Bank angle indicators - check for wear ³
<input type="checkbox"/>	<input type="checkbox"/>	Fasteners - inspect visually for security
<input type="checkbox"/>	<input type="checkbox"/>	Accessory rack sliding carriage - check for correct operation - except first service (Trophy, Trophy SE, Tiger Explorer only)
<input type="checkbox"/>	<input type="checkbox"/>	Accessory pannier link mechanism - check for correct operation and adjustment (Trophy, Trophy SE, Tiger Explorer only)
<input type="checkbox"/>	<input type="checkbox"/>	Centre and/or side stand - check for wear/smooth operation
<input type="checkbox"/>	<input type="checkbox"/>	Centre stand flanged sleeves (if fitted) clean/grease
<input type="checkbox"/>	<input type="checkbox"/>	Side stand pivot pin - clean/grease
<input type="checkbox"/>	<input type="checkbox"/>	Gear change pedal - clean bushes (Tiger Explorer only)
<input type="checkbox"/>	<input type="checkbox"/>	Carry out all outstanding Service Bulletin and warranty work
<input type="checkbox"/>	<input type="checkbox"/>	Carry out road test
<input type="checkbox"/>	<input type="checkbox"/>	Complete the service record book and reset the service indicator (if fitted)

Note:

The following notes must be referred to as necessary during scheduled servicing:

¹ If applicable.

² If fitted.

³ Renew checked items if worn beyond the service limit.

⁴ **Additional** items are subject to additional labour charge, above the cost and time allowance for the basic service, which includes time to check only.

Daily checks must also be carried out as specified in the Owner's Handbook.